



PROTERMSTEP ACC

POLISHED, SATIN FINISH STAINLESS STEEL AISI 304/1.4301-V2A

PROTERMSTEP ACC is the new step cover profile made of stainless steel. Designed to protect the edge of the step and to hide the joint between the tread and the step rise. The special notched shape in the upright stem provides it with excellent anchorage between floor/glue/profile. Reversible profile.



EXAMPLES OF LAYING for instructions see the product below



POLISHED STAINLESS STEEL AISI 304/1.4301-V2A with protective film
bar length 2,7 lm - pack 15 Pcs - 40,5 lm

Article	h / H mm		
PTSPAC 0815	08 / 15		
PTSPAC 10125	10 / 12,5		
PTSPAC 1530	15 / 30		
PTSPAC 2025	20 / 25		

SATIN FINISH STAINLESS ST. AISI 304/1.4301-V2A
bar length 2,7 lm - pack 15 Pcs - 40,5 lm

Article	h / H mm		
PTSPACS 0815	08 / 15		*
PTSPACS 10125	10 / 12,5		*
PTSPACS 1530	15 / 30		*
PTSPACS 2025	20 / 25		*


EXTERNAL CORNERS - pack 10 Pcs

Article	h / H mm		
REPTSAC 0815	08 / 15		
REPTSAC 10125	10 / 12,5		
REPTSAC 1530	15 / 30		
REPTSAC 2025	20 / 25		

JUNCTION H 10 - 12,5 - 15 - 20 mm - pack 10 Pcs

Article	h / H mm		
GIPTSAC 0815	08 / 15		
GIPTSAC 10125	10 / 12,5		
GIPTSAC 1530	15 / 30		
GIPTSAC 2025	20 / 25		

COLOURS





SUITABLE FOR USE IN CONTACT WITH FOODSTUFFS



PROTERMSTEP ALL

NATURAL AND ANODISED SILVER ALUMINIUM

PROTERMSTEP ALL is the new step cover profile made of natural and anodised aluminium. Designed to protect the edge of the step and to hide the joint between the tread and the step rise. The special notched shape in the upright stem provides it with excellent anchorage between floor/glue/profile.



EXAMPLES AND INSTRUCTIONS FOR LAYING METHODS



NATURAL ALUMINIUM
bar length 2,7 lm - pack 20 Pcs - 54 lm

Article	H mm		
PTSPAN 08	8		
PTSPAN 10	10		
PTSPAN 125	12,5		
PTSPAN 15	15		

ANODISED SILVER ALUMINIUM thermo packed
bar length 2,7 lm - pack 20 Pcs - 54 lm

Article	H mm		
PTSPAA 08	8		
PTSPAA 10	10		
PTSPAA 125	12,5		
PTSPAA 15	15		

COLOURS



1. Choose the PROTERMSTEP in the required width and colour according to the thickness of the tile (stairs).
2. First fix the riser part, placing it at the correct and final height.
3. Fill the empty spaces under the profile with the tile adhesive.
4. Apply the adhesive to the tread, lay the profile with the punched base fully sunk into the adhesive and align the profile so that its lip covers the edge of the riser tile.
5. Lay the tread tiles, aligning them so that they are flush with the upper and rear part of the profile and filling the internal part with adhesive.

* = On demand, price and delivery time to be agreed.