


# OPERATION AND MAINTENANCE OF THE CLEAN SYSTEM DOORMATS

The proper functioning of the doormats is dependent upon their correct assembly. The key under a doormat should be even, with a depth equal to the doormat's height (acceptable difference is 2 mm). An uneven floor under the doormat may irreversibly deform the structural profiles and invalidate the warranty.



## ■ CLEANING:

From time to time, wet- clean the doormat using carpet cleaning devices (extractors), chemical agents that do not damage rubber and aluminium. Recommended cleaning frequency: every two weeks or more often, depending on the level of dirtiness and the season (rainfall and snow).




### LIGHT IMPURITIES

After rolling the mat, impurities under the profiles should be removed using a vacuum cleaner



### MEDIUM IMPURITIES

After rolling the mat and vacuuming the space underneath, fillings should be additionally cleaned with a vacuum cleaner.



### HARD IMPURITIES

After vacuuming and cleaning it with a brush, the mat should be cleaned with a pressure washer. The mat should be put back only when it is completely dry.



## ■ CHANGING THE CLEANING FILLINGS

Mats can be destroyed due to their inappropriate use (throwing cigarette butts, chewing gum, and greasy substances). Such situations happen frequently, which is why we ensured that this damage can be repaired in a simple and easy way. The frame remains in place, and repairing is fast and economical

## ■ THE CLEAN SYSTEM DOORMATS ARE RESISTANT TO:

- table salt
- snow melting agents
- common chemicals not containing chlorine

## ■ TECHNICAL DECLARATION

- cord type: (stainless) steel, galvanized cord Ø3 mm
- metal elements material: aluminium
- drying insert material: 100% polypropylene, rubber mix, brush insert
- damper: waterproof foam tape
- design: open, with high dirt capacity, rolled
- installation: in a recess made in the floor to ensure that the upper surface of the doormat is flush with the floor, or with a sloped transition laid on the floor.
- attestations and approvals: PZH certificate HK/B/0628/01/2014, ITB opinion NJ-5/KR/1106/09, material test report NO. 12/17BB.903.0290.01, anti-slip class according to standard DIN 51130: 2014-02, fire resistance classification Cfl-s1.



load-bearing profile height:  
12, 15 and 19 mm



1 m<sup>2</sup> weight: from 12 up to 20 kg  
(depending on the height of the  
transition profiles and the insert  
material used)



custom sizes:  
max. width: 6 m  
max. length: 10 m



range of temperatures:  
from -25°C to +70°C



acceptable loads:  
2500 kg/100 cm<sup>2</sup>



application:  
inside and outside buildings

## ■ GUARANTEE CONDITIONS

Facility Flooring grants a warranty for the product named: clean system shoe doormat, for a period of 3 years, counting from the date of its sale, for the structures (the profile, the cord etc.) The warranty does not cover the cleaning elements that are subject to normal wear and tear.

Facility Flooring shall bear liability under the warranty for their doormats, when the damage results from causes inherent to the products sold. Upon transferring the products, the risk of their accidental loss or damage passes to the Buyer.

## ■ THE WARRANTY DOES NOT COVER:

- mechanical damages resulting from incorrect use of doormats (e.g. any damage caused as a result of turning, pulling, pushing, driving heavy equipment over a doormat - in particular cleaning machines and forklifts or sharp objects),
- damage arising from choosing wrong doormat type for the present or expected operational conditions (traffic intensity, transport truck load etc.)
- damage arising from improper storage and transportation,
- damage arising from improper installation and reworks,
- reduced operational properties of doormats caused by insufficient maintenance (cleaning, removal of chewing gum, replacing damaged inserts).